

# NONWOVEN PREMIUM MATTE INSTALLATION INSTRUCTIONS BUTT SEAMS

## FAILURE TO FOLLOW INSTRUCTIONS WILL VOID ANY REFUND

1. **Before installation of goods, examine rolls for color, and variance in shading. Pre-plan your installation by laying out strips and inspecting before hanging. If the wallcovering is not satisfactory, contact manufacturer and do not install.**
2. All hanging surfaces must be clean, smooth, dry, undamaged, free of mold, mildew, grease or stains. All loose paint and other wallcoverings should be removed.
3. **Prepare wall with GARDZ or similar primer.** Allow primer to dry fully before continuing.
4. **Use a pre-mixed clear professional grade adhesive.** The adhesive should be whipped/mixed thoroughly to ensure smooth even application. Roll adhesive to back of panel by hand or use a pasting machine. Do not paste wall.
5. Carefully lay ends of panel in onto itself without creasing. Adhesive side of panel should be completely stuck to itself.
6. Measure wall and panel width to determine the edge of the first panel. Use a level to ensure plum. Unfold roll and place it on the wall starting from the top.
7. Using broad smooth strokes work excess paste and trapped air from center out left and right until panel is smooth. Avoid burnishing the face of the material. Use a wallcovering brush or a plastic scraper to gently smooth the wallcovering onto the wall.
8. Repeat process with consecutive panels. Butt edges tightly at the pattern match without overlapping. Cut ceiling and floor cuts before moving to next panel.
9. Do not rub. Do not allow the adhesive to dry on surface as it may leave a white residue. Wash off excess paste from face of wallcovering as you hang it with a cellulose sponge. The cellulose sponge must be rinsed in clean water after every use. Blot dry with a clean cloth. No scrubbing, abrasive or solvent cleaners. Use seam roller to make sure all seams are bonded well.
10. **After three panels are smoothed to wall surface and excess paste removed, examine the installed panels for color uniformity. Any objectionable variations in colormatch, pattern match, etc...should be immediately communicated to DWC for inspection before proceeding further with installation.**
11. After installation is complete, minor blisters like small bubbles may be present. Please allow 7 days for adhesive to fully cure. As wallpaper cures it will tighten like a drum and pull taught any minor blisters. Do not try to press them down with your finger. The walls and wallcovering should be monitored for potential moisture or vapor infiltration or accumulation. Any such infiltration/accumulation after installation must be promptly eliminated in order to reduce the risk of mold/mildew growth.